

Air Purifier Hygeolis

Do not mask the odors, **eliminate them!**



Mano
Médical
by génia

High-performance filtration for exceptional results



Hygeolis draws in stale air through the front and releases healthy air at 270° for optimum efficiency, whether free-standing or wall-mounted.

The challenges of air quality (physical, chemical and bacteriological) in veterinary clinics



Protecting staff

- ✓ Safety at work
- ✓ Prevention of occupational illness



Protecting animals

- ✓ Limiting cross-contamination
- ✓ Use in all areas of the clinic (kennels, reception, etc.)



Improving working and reception conditions

- ✓ Odor elimination
- ✓ Team well-being
- ✓ Enhancing the image of the clinic



22 rue Charles de Gaulle
22100 Lanvallay - France
Tel. +33 (0)2 96 85 86 76

export@manomedical.com

www.manomedical.com

Elimination of odors and micro-organisms



Efficient

- ▶ Continuous odor elimination or Clean Booster mode: 30-minute ozone-powered cycle to eliminate micro-organisms
- ▶ 4 filtering levels including a biocide filter and a very high-density activated coal filter
- ▶ 3 fan speeds

User-friendly

- ▶ Compact, lightweight and easily transportable
- ▶ Plug & Play
- ▶ Silent
- ▶ Remote control included
- ▶ Easy maintenance: one replaceable filter block

Eco-friendly

- ▶ Made in France
- ▶ Single-material structure, colorant-free, glue-free and paint-free, totally recyclable
- ▶ Filter block replacement once a year (for 8h/day workload)



Patented technology

Wherever odors persist, Hygeolis ensures healthy and clean air every day, without perfumes or chemicals, thanks to its exclusive filtration technology.



Hygeolis - Revolutionary air purifier



Controlled active oxygen technology

This technology can be activated or deactivated to generate active oxygen, a natural detergent, in a controlled manner. Two air treatment modes are available:

- **Continuous** (mode 1)

In this mode, the Hygeolis will eliminate all odors using its powerful filtration system, while remaining perfectly safe for any living beings.

- **Clean Booster** (mode 2)

In this mode, Hygeolis will successfully eliminate not only odors, but also viruses, bacteria and spores through the usage of active oxygen. This mode is activated on command for 30 minute cycles with the remote control, **and must be run in a closed room with no animal or human presence.**

MODE
CLEAN
BOOSTER
30 MIN

- Technical features :

▶ Treated area:	Recommended : 30 m ² - maximum : 45 m ²
▶ Size (h. x l. x d.)	23 x 23 x 19 cm
▶ Weight (including filters)	4,2 kg
▶ Min/max power input	3 - 12 W
▶ Ventilation speeds	3
▶ Max airflow	150 m ³ /hour
▶ Noise level min / max	35 -52 dB
▶ Secure wall mounting	Included
▶ Power supply	220V or 12V / 50 - 60 Hz
▶ Protection class	IP23
▶ Filter blocks	Removable bactericidal, acaricidal and virucidal pre-filter ISO 18184 and NF G39-011-certified
	Very High Density activated carbon filter
▶ Activatable active oxygen technology	<ul style="list-style-type: none"> • Mode 1: Continuous air treatment • Mode 2: Intensive air treatment (Clean Booster 30 min)
▶ Settings	On device or via remote control
▶ Indicators	Filter wear indicator
	ON/OFF/Standby



22 rue Charles de Gaulle
22100 Lanvallay - France
Tel. +33 (0)2 96 85 86 76

export@manomedical.com

www.manomedical.com